
Thermostat, Cooling, 50-90°F Set Point Range, Product # 386367



When the temperature in the space rises above the set point of 50 F - 90 F the contacts close and the thermostat will signal the fan to come on in order to exhaust air from the space. Includes face mounted thermometer that displays room temperature.

Certifications

Performance Characteristics

No Fan Curve Available.